

SELLALASTIC FOAM

Standardized according to DIN18.540

Ultra-elastic polyethylene cord for filling the bottom of expansion joints.



Grey

HOW TO USE

SUPPORT PREPARATION

-The correct, exhaustive and detailed restoration of the substrate is the best guarantee to ensure a long-lasting bond. Remove any remains of deteriorated concrete, unsound concrete, traces of dust, paint, release agents, waxes, ...

PRODUCT PREPARATION

-**SELLALASTIC FOAM** is a ready-to-use product.

PRODUCT APPLICATION

-Apply the **SELLALASTIC FOAM** under pressure so that the diameter of the **SELLALASTIC FOAM** is always 5 mm wider than the joint to be sealed. For example:

- For expansion joints 10 mm wide, use the 15 mm cord.
- For 15 mm wide expansion joints, use the 20 mm cord.
- For 20 mm wide expansion joints, use the 25 mm cord.
- For expansion joints 25 mm wide, use the 30 mm cord.
- For expansion joints of 35 mm width, use the 40 mm cord.
- Press the cord into the joint.
- Leave a depth of 1 cm for the filler.

COMMENTS TO TAKE INTO ACCOUNT

-**SELLALASTIC FOAM** is supplied by linear meters in its different diameters.

TECHNICAL DATA

Type of polyethylene foam	closed cell
Density	24 kg/m ³
Toxicity	harmless
Temperature of application	from +1°C to +40°C
Elongation at break	65%
Resistance to shearing	2.2 kg/cm ²
Range of working temperatures	from -40°C to +60°C
UV resistance	unlimited
Chemical resistance	not suitable for hot asphalt
Consumption	1 m / 1 m
Estimated expiration	unlimited
Presentation - diameters	15, 20, 25, 30 and 40 mm

MAIN FEATURES

- Closed cell polyethylene foam cord.
- Maximum elasticity and durability.
- Do not use for other uses than those specified here without previous consultation with our technical department.
- Do not use as a finishing product: it needs to be covered with elastic fillers to fulfill the correct function of an expansion joint.

FIELD OF APPLICATION

- Ideal for filling the expansion joint previous to sealing with **SILICONA NEUTRA-FIXCER**, with **SELLALASTIC**, **SELLAFIX** or **SELLADOR S10**.
- With **SELLALASTIC FOAM** we ensure that the depth of the movement joint never exceeds the width of the joint.
- Closed cell polyethylene cord for use as a filler in expansion joints before the application of elastic mastic.

